

## **Method statement for Cem-Rock™ and internal partition application**

### **Finished surface**

1. Before boards are installed, ensure your timber studs or metal studs are secured and installed in maximum 600mm centres, levelled, plumbed and in alignment.
2. Install the Cem-Rock™ Cement Boards onto the studs using proper Greenspan approved Alkali Resistant or Stainless Steel Screws (4x40mm). Screws spacing should not exceed 200mm. Minimum distance of the screw from the edge of the board is 15mm. There should be gaps of 2-3mm left between the boards to allow for proper joints treatment. Boards should be installed staggered in horizontal rows and in the corners. Haunch boards around corners of window and door reveals.
3. Make sure the boards are installed smooth side out.
4. Tape and fill the joints with a jointing compound (i.e. Sheetrock® PLUS3) and scrim tape to required level finish.
5. Apply a jointing compound (i.e. Sheetrock® PLUS3) over each screw head.
6. Apply a primer and paint to dried surface to paint supplier specification.

For further information contact the Greenspan Technical Department.

Phone: 00353 69 82222  
Fax: 00353 69 82226  
E-mail: [sales@greenspan.ie](mailto:sales@greenspan.ie)  
Website: [www.greenspan.ie](http://www.greenspan.ie)